

The Chargemaster Output Splitter provides four power connections from a single power supply outlet. See your Chargemaster Operation Manual for the current limits specific to the power supply used.

**CAUTION:** When connecting additional charging devices through the splitter, it is important to not exceed the maximum rated current limit of the power supply.

## Tape Mount

1. Select a flat, rigid, grease-free surface not exceeding 120°F in temperature.
2. Remove paper liner from mounting tape to expose the adhesive surface.
3. Press unit firmly onto surface.

## Splitter Removal

1. The output splitter may be removed from the mounting surface (for cable connection) by pulling apart the tape halves. Remount the unit by aligning the tape edges and pressing down.

## Screw Mount

1. Select a flat, rigid surface or structural member.
2. Use the two mounting holes on the unit as a template to mark screw locations on mounting surface, or mark on 2-1/2" centers. Note: Two #10 screws are necessary but not provided.

**CAUTION:** Use holes provided in the splitter unit only; holes drilled elsewhere in the unit may cause arcing and shutdown.

3. Tighten all mounting hardware securely.

Model 4005019 (for Chargemaster Models CM20, CH20, VCM30, VCM BP30, CH/BP30)

Model 4005020 (for Chargemaster Models VCM60, VCM BP60, CH/BP50 only)

